

```

EEEEEEEEEEEEEEEEEE      RRRRRRRRRRRR      FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE      RRRRRRRRRRRR      FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE      RRRRRRRRRRRR      FFFFFFFFFFFFFFFF
EEE                      RRR                RRR      FFF
EEE                      RRR                RRR      FFF
EEE                      RRR                RRR      FFF
EEE                      RRR                RRR      FFF
EEE                      RRR                RRR      FFF
EEE                      RRR                RRR      FFF
EEEEEEEEEEEEEEEEEE      RRRRRRRRRRRR      FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE      RRRRRRRRRRRR      FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE      RRRRRRRRRRRR      FFFFFFFFFFFFFFFF
EEE                      RRR                RRR      FFF
EEE                      RRR                RRR      FFF
EEE                      RRR                RRR      FFF
EEE                      RRR                RRR      FFF
EEE                      RRR                RRR      FFF
EEEEEEEEEEEEEEEEEE      RRRRRRRRRRRR      FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE      RRRRRRRRRRRR      FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE      RRRRRRRRRRRR      FFFFFFFFFFFFFFFF

```

[illegible]

```

TTTTTTTTTTT  UU      UU      TTTTTTTTTTT  AAAAAA  PPPPPPP  EEEEEEEEEEE
TTTTTTTTTTT  UU      UU      TTTTTTTTTTT  AAAAAA  PPPPPPP  EEEEEEEEEEE
      TT      UU      UU      TT      AA      AA  PP      PP  EE
      TT      UU      UU      TT      AA      AA  PP      PP  EE
      TT      UU      UU      TT      AA      AA  PP      PP  EE
      TT      UU      UU      TT      AA      AA  PP      PP  EE
      TT      UU      UU      TT      AA      AA  PPPPPPP  EEEEEEEEE
      TT      UU      UU      TT      AA      AA  PPPPPPP  EEEEEEEEE
      TT      UU      UU      TT      AAAAAAAAA  PP      EE
      TT      UU      UU      TT      AAAAAAAAA  PP      EE
      TT      UU      UU      TT      AA      AA  PP      EE
      TT      UU      UU      TT      AA      AA  PP      EE
      TT      UU      UU      TT      AA      AA  PP      EE
      TT      UU      UU      TT      AA      AA  PP      EE
      TT      UUUUUUUUU  TT      AA      AA  PP      EEEEEEEEE
      TT      UUUUUUUUU  TT      AA      AA  PP      EEEEEEEEE

```

```

LL      IIIIII  SSSSSSSS
LL      IIIIII  SSSSSSSS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SSSSSS
LL      II      SSSSSS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SS
LLLLLLLLLLL  IIIIII  SSSSSSSS
LLLLLLLLLLL  IIIIII  SSSSSSSS

```

000
000
000
000
000
000
027
027
027
027
027
027
027
027
027
028
028
028
028
028
028
028
028
028
028
029
029
029
029
029
029
029
029
029
029
030
030
030
030
030
030
030
030
030
031
031
031
031
031
031
031
031
031
032

C 11
16-Sep-1984 00:16:59
5-Sep-1984 14:24:09

VAX-11 FORTRAN V3.4-56
DISK\$VMSMASTER:[ERF.SRC]TUTAPE.FOR;1 Page 1

```
0001 SUBROUTINE TUTAPE (LUN)
0002 C
0003 C Version: 'V04-000'
0004 C
0005 C*****
0006 C*
0007 C* COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0008 C* DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0009 C* ALL RIGHTS RESERVED.
0010 C*
0011 C* THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0012 C* ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0013 C* INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0014 C* COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0015 C* OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0016 C* TRANSFERRED.
0017 C*
0018 C* THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0019 C* AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0020 C* CORPORATION.
0021 C*
0022 C* DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0023 C* SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0024 C*
0025 C*
0026 C*****
0027 C
0028 C
0029 C
0030 C AUTHOR BRIAN PORTER CREATION DATE 5-OCT-1979
0031 C
0032 C Fucntional description:
0033 C
0034 C This module displays TU58 errors.
0035 C
0036 C Modified by:
0037 C
0038 C V03-004 SAR0236 Sharon A. Reynolds, 28-Mar-1984
0039 C Changed the call to UCBSL_OWNUIC to ORBSL_OWNER.
0040 C
0041 C V03-003 SAR0130 Sharon A. Reynolds, 8-Sep-1983
0042 C Changed the overprint carriage control in the 'format'
0043 C statements for use with ERF.
0044 C
0045 C V03-002 SAR0100 Sharon A. Reynolds, 20-Jun-1983
0046 C Changed the carriage control in the 'format' statements
0047 C for use with ERF.
0048 C
0049 C V03-001 SAR0052 Sharon A. Reynolds, 13-Jun-1983
0050 C Removed brief/cryptic support.
0051 C
0052 C v02-004 BP0004 Brian Porter, 23-NOV-1981
0053 C Minor edit.
0054 C
0055 C v02-003 BP0003 Brian Porter, 05-NOV-1981
0056 C Added 'device attention' support.
0057 C
```


D 11
16-Sep-1984 00:16:59
5-Sep-1984 14:24:09

VAX-11 FORTRAN V3.4-56
DISK\$VMSMASTER:[ERF.SRC]TUTAPE.FOR;1

Page 2

0058 C
0059 C
0060 C
0061 C
0062 C
0063 C
0064 C**
0065
0066
0125
0226
0227
0228
0229
0230
0231
0232
0233
0234
0235
0236
0237
0238
0239
0240
0241
0242
0243
0244
0245
0246
0247
0248
0249
0250
0251
0252
0253
0254
0255
0256
0257
0258
0259
0260
0261
0262
0263
0264
0265
0266
0267
0268
0269
0270
0271
0272

v02-002 BP0002 Brian Porter, 01-JUL-1981
Added call to LOGGER and DHEAD. Added DIAGNOSTIC_MODE.

v02-001 BP0001 Brian Porter, 19-JUL-1980
Corrected Fortran format error when end packet has illegal
byte count. Removed call to UNUSED_BITS.

INCLUDE 'SRC\$:MSGHDR.FOR /NOLIST'
INCLUDE 'SRC\$:DEVERR.FOR /NOLIST'

BYTE LUN
BYTE CMD_PKT(0:13)
BYTE END_PKT(0:13)

INTEGER*4 FIELD
INTEGER*4 RCSR
INTEGER*4 RBUF
INTEGER*4 XCSR
INTEGER*4 XBUF
INTEGER*4 COMPRESS4
INTEGER*4 COMPRESSC

logical*1 diagnostic_mode

PARAMETER TIMEOUT = 96
PARAMETER READ = 2
PARAMETER WRITE = 3
PARAMETER POSITION = 5

EQUIVALENCE (EMBSL_DV_REGS(0),XCSR)
EQUIVALENCE (EMBSL_DV_REGS(1),XBUF)
EQUIVALENCE (EMBSL_DV_REGS(2),RCSR)
EQUIVALENCE (EMBSL_DV_REGS(3),RBUF)
EQUIVALENCE (EMB(98),CMD_PKT(0))
EQUIVALENCE (EMB(112),END_PKT(0))

CHARACTER*14 UNIT_NUMBER
DATA UNIT_NUMBER /'UNIT NUMBER = '/

CHARACTER*11 UNUSED_BYTE
DATA UNUSED_BYTE /'UNUSED BYTE'/

CHARACTER*19 CONTROL_PACKET
DATA CONTROL_PACKET /'TU58 CONTROL PACKET'/

CHARACTER*14 COMMAND_PACKET
DATA COMMAND_PACKET /'COMMAND PACKET'/

CHARACTER*7 OP_CODE
DATA OP_CODE /'OP CODE'/

CHARACTER*17 PBYTE_COUNT
DATA PBYTE_COUNT /'PACKET BYTE COUNT'/

```
0273 CHARACTER*15 SEQUENCE_LO
0274 DATA SEQUENCE_LO 7'SEQUENCE LO, HI'/
0275
0276 CHARACTER*17 BYTECOUNT_LO
0277 DATA BYTECOUNT_LO 7'BYTE COUNT LO, HI'/
0278
0279 CHARACTER*19 BLOCK_LO
0280 DATA BLOCK_LO 7'BLOCK NUMBER LO, HI'/
0281
0282 CHARACTER*15 CHECKSUM_LO
0283 DATA CHECKSUM_LO 7'CHECKSUM LO, HI'/
0284
0285 CHARACTER*17 V1RCSR(6:7)
0286 DATA V1RCSR(6) 7'INTERRUPT ENABLE*'/
0287 DATA V1RCSR(7) 7'RECEIVER DONE*'/
0288
0289 CHARACTER*16 V2RCSR(11:11)
0290 DATA V2RCSR(11) 7'RECEIVER ACTIVE*'/
0291
0292 CHARACTER*15 V1RBUF(12:15)
0293 DATA V1RBUF(12) 7'PARITY ERROR*'/
0294 DATA V1RBUF(13) 7'FRAMING ERROR*'/
0295 DATA V1RBUF(14) 7'OVER-RUN ERROR*'/
0296 DATA V1RBUF(15) 7'ERROR*'/
0297
0298 CHARACTER*6 V1XCSR(0:0)
0299 DATA V1XCSR(0) 7'BREAK*'/
0300
0301 CHARACTER*18 V2XCSR(6:7)
0302 DATA V2XCSR(6) 7'INTERRUPT ENABLE*'/
0303 DATA V2XCSR(7) 7'TRANSMITTER READY*'/
0304
0305 CHARACTER*20 V1OP_CODE(-1:12)
0306 DATA V1OP_CODE(-1) 7'ILLEGAL FUNCTION*'/
0307 DATA V1OP_CODE(0) 7'NO OPERATION*'/
0308 DATA V1OP_CODE(1) 7'INITIALIZE*'/
0309 DATA V1OP_CODE(2) 7'READ*'/
0310 DATA V1OP_CODE(3) 7'WRITE*'/
0311 DATA V1OP_CODE(4) 7'COMPARE*'/
0312 DATA V1OP_CODE(5) 7'POSITION*'/
0313 DATA V1OP_CODE(6) 7'ABORT*'/
0314 DATA V1OP_CODE(7) 7'DIAGNOSE*'/
0315 DATA V1OP_CODE(8) 7'GET STATUS*'/
0316 DATA V1OP_CODE(9) 7'SET STATUS*'/
0317 DATA V1OP_CODE(10) 7'GET CHARACTERISTICS*'/
0318 DATA V1OP_CODE(11) 7'SET CHARACTERISTICS*'/
0319 DATA V1OP_CODE(12) 7'ILLEGAL FUNCTION*'/
0320
0321 CHARACTER*16 V2OP_CODE(63:65)
0322 DATA V2OP_CODE(63) 7'ILLEGAL OP CODE*'/
0323 DATA V2OP_CODE(64) 7'SEND END PACKET*'/
0324 DATA V2OP_CODE(65) 7'ILLEGAL OP CODE*'/
0325
0326 CHARACTER*10 MODIFIER(0:0)
0327 DATA MODIFIER(0) 7'DATACHECK*'/
0328
0329
```



```

0330
0331 CHARACTER*18 V1SUM_STATUS(4:7)
0332 DATA V1SUM_STATUS(4)/'LOGIC ERROR*'/
0333 DATA V1SUM_STATUS(5)/'MOTION ERROR*'/
0334 DATA V1SUM_STATUS(6)/'TRANSFER ERROR*'/
0335 DATA V1SUM_STATUS(7)/'SPECIAL CONDITION*'/
0336
0337 BYTE V1SUCCESS_CODE(0:11)
0338 DATA V1SUCCESS_CODE(0)7'00'X/
0339 DATA V1SUCCESS_CODE(1)7'01'X/
0340 DATA V1SUCCESS_CODE(2)7'FF'X/
0341 DATA V1SUCCESS_CODE(3)7'FE'X/
0342 DATA V1SUCCESS_CODE(4)7'F8'X/
0343 DATA V1SUCCESS_CODE(5)7'F7'X/
0344 DATA V1SUCCESS_CODE(6)7'F5'X/
0345 DATA V1SUCCESS_CODE(7)7'EF'X/
0346 DATA V1SUCCESS_CODE(8)7'E0'X/
0347 DATA V1SUCCESS_CODE(9)7'DF'X/
0348 DATA V1SUCCESS_CODE(10)7'D0'X/
0349 DATA V1SUCCESS_CODE(11)7'C9'X/
0350
0351 CHARACTER*22 V2SUCCESS_CODE(0:12)
0352 DATA V2SUCCESS_CODE(0)7'NORMAL COMPLETION*'/
0353 DATA V2SUCCESS_CODE(1)7'RETRY COMPLETION*'/
0354 DATA V2SUCCESS_CODE(2)7'SELF TEST FAILURE*'/
0355 DATA V2SUCCESS_CODE(3)7'PARTIAL OPERATION*'/
0356 DATA V2SUCCESS_CODE(4)7'INVALID UNIT NUMBER*'/
0357 DATA V2SUCCESS_CODE(5)7'NO CARTRIDGE PRESENT*'/
0358 DATA V2SUCCESS_CODE(6)7'WRITE PROTECTED*'/
0359 DATA V2SUCCESS_CODE(7)7'DATA CHECK*'/
0360 DATA V2SUCCESS_CODE(8)7'BLOCK NOT FOUND*'/
0361 DATA V2SUCCESS_CODE(9)7'MOTOR STOPPED*'/
0362 DATA V2SUCCESS_CODE(10)7'INVALID OP CODE*'/
0363 DATA V2SUCCESS_CODE(11)7'INVALID RECORD NUMBER*'/
0364 DATA V2SUCCESS_CODE(12)7'ILLEGAL SUCCESS CODE*'/
0365
0366 CHARACTER*9 BYTE_COUNT(9:11)
0367 DATA BYTE_COUNT(9)7' ILLEGAL*'/
0368 DATA BYTE_COUNT(10)7' = 10.*'/
0369 DATA BYTE_COUNT(11)7' ILLEGAL*'/
0370
0371
0372 CALL FRCTOF (LUN)
0373
0374 if (emb$t_dv_name(1:3) .eq. 'CSA') then
0375
0376 call dhead1 (lun,'CONSOLE TU58')
0377 else
0378
0379 call dhead1 (lun,'UBA TU58')
0380 endif
0381
0382 diagnostic_mode = .false.
0383
0384 if (lib$extzv(2,1,xcsr) .eq. 1) diagnostic_mode = .true.
0385
0386 CALL LINCHK (LUN,2)

```

```
0387
0388
0389 10  WRITE(LUN,10) RCSR
0390      FORMAT(/' ',T8,'RCSR',T24,Z8.4)
0391      if (.not. diagnostic_mode) then
0392
0393      CALL OUTPUT (LUN,RCSR,V1RCSR,6,6,7,'0')
0394
0395      CALL OUTPUT (LUN,RCSR,V2RCSR,11,11,11,'0')
0396      endif
0397
0398      CALL LINCHK (LUN,1)
0399
0400 15  WRITE(LUN,15) RBUF
0401      FORMAT(' ',T8,'RBUF',T24,Z8.4)
0402
0403      if (.not. diagnostic_mode) then
0404
0405      DO 19,I = 12,15
0406
0407      IF (JIAND(RBUF,2**I) .NE. 0) THEN
0408
0409      CALL LINCHK (LUN,1)
0410
0411 18  WRITE(LUN,18) V1RBUF(I)
0412      FORMAT(' ',T40,'RECEIVE DATA ',A<COMPRESSC (V1RBUF(I))>)
0413      ENDIF
0414
0415 19  CONTINUE
0416      endif
0417
0418      CALL LINCHK (LUN,1)
0419
0420 20  WRITE(LUN,20) XCSR
0421      FORMAT(' ',T8,'XCSR',T24,Z8.4)
0422
0423      if (.not. diagnostic_mode) then
0424
0425      CALL OUTPUT (LUN,XCSR,V1XCSR,0,0,0,'0')
0426
0427      CALL OUTPUT (LUN,XCSR,V2XCSR,6,6,7,'0')
0428      else
0429
0430      CALL LINCHK (LUN,1)
0431
0432 25  WRITE(LUN,25)
0433      FORMAT(' ',T40,'DIAGNOSTIC MODE')
0434      endif
0435
0436      CALL LINCHK (LUN,1)
0437
0438 30  WRITE (LUN,30) XBUF
0439      FORMAT(' ',T8,'XBUF',T24,Z8.4)
0440
0441      if (.not. diagnostic_mode) then
0442
0443      CALL LINCHK (LUN,3)
```

```
0444
0445      IF (CMD_PKT(0) .NE. 2) THEN
0446
0447      WRITE(LUN,40)
0448 40      FORMAT(/' ', 'COMMAND PACKET HAS INVALID FLAG',/)
0449
0450      DO 44,I = 0,14
0451
0452      CALL LINCHK (LUN,1)
0453
0454      WRITE(LUN,42) CMD_PKT(1)
0455 42      FORMAT(' ',T30,Z2.2)
0456
0457 44      CONTINUE
0458      ELSE
0459
0460      WRITE(LUN,45)
0461 45      FORMAT(/' ', 'COMMAND MESSAGE PACKET',/)
0462
0463      CALL LINCHK (LUN,2)
0464
0465      WRITE(LUN,50) CMD_PKT(0),CONTROL_PACKET
0466 50      FORMAT(' ',T8,'FLAG',T30,Z2.2,/,T40,A19)
0467
0468      CALL LINCHK (LUN,2)
0469
0470      FIELD = LIB$EXTZV(0,8,CMD_PKT(1))
0471
0472      WRITE(LUN,55) PBYTE_COUNT,CMD_PKT(1),PBYTE_COUNT,
0473      1 BYTE_COUNT(MAX(9,MIN(11,FIELD)))
0474 55      FORMAT(' ',T8,A17,T30,Z2.2,/,
0475      1 T40,A17,A<COMPRESSC (BYTE_COUNT(MAX(9,MIN(11,FIELD))))>>)
0476
0477      CALL LINCHK (LUN,2)
0478
0479      FIELD = LIB$EXTZV(0,8,CMD_PKT(2))
0480
0481      WRITE(LUN,60) OP_CODE,CMD_PKT(2),V1OP_CODE(MAX(-1,MIN(11,FIELD)))
0482 60      FORMAT(' ',T8,A7,T30,Z2.2,/,T40,
0483      1 'FUNCTION = ',A<COMPRESSC (V1OP_CODE(MAX(-1,MIN(11,FIELD))))>>)
0484
0485      CALL LINCHK (LUN,1)
0486
0487      WRITE(LUN,65) CMD_PKT(3)
0488 65      FORMAT(' ',T8,'OP-CODE MODIFIER',T30,Z2.2)
0489
0490      CALL OUTPUT (LUN,CMD_PKT(3),MODIFIER,0,0,0,'0')
0491
0492      CALL LINCHK (LUN,2)
0493
0494      FIELD = LIB$EXTZV(0,8,CMD_PKT(4))
0495
0496      WRITE(LUN,68) CMD_PKT(4),UNIT_NUMBER,FIELD
0497 68      FORMAT(' ',T8,'UNIT',T30,Z2.2,/,
0498      1 T40,A14,I<COMPRESS4 (FIELD)>,>,'.')
0499
0500      CALL LINCHK (LUN,1)
```



```
0501
0502      70  WRITE(LUN,70) UNUSED_BYTE,CMD_PKT(5)
0503      FORMAT(' ',T8,A11,T30,Z2.2)
0504
0505      CALL LINCHK (LUN,2)
0506
0507      75  WRITE(LUN,75) SEQUENCE_LO,CMD_PKT(6),CMD_PKT(7)
0508      FORMAT(' ',T8,A15,T30,Z2.2,/,T30,Z2.2)
0509
0510      CALL LINCHK (LUN,2)
0511
0512      80  WRITE(LUN,80) BYTECOUNT_LO,CMD_PKT(8)
0513      FORMAT(' ',T8,A17,T30,Z2.2)
0514
0515      Field = ' '
0516
0517      IF (CMD_PKT(2) .EQ. READ
0518      1 .OR.
0519      2 CMD_PKT(2) .EQ. WRITE) THEN
0520
0521      FIELD = LIB$EXTZV(0,16,CMD_PKT(8))
0522      ENDIF
0523
0524      85  WRITE(LUN,85) CMD_PKT(9),FIELD
0525      FORMAT(' ',T30,Z2.2,/,T40,
0526      1 'TRANSFER BYTE COUNT = ',I<COMPRESS4 (FIELD)>,'.')
0527
0528      CALL LINCHK (LUN,2)
0529
0530      90  WRITE(LUN,90) BLOCK_LO,CMD_PKT(10)
0531      FORMAT(' ',T8,A19,T30,Z2.2)
0532
0533      Field = ' '
0534
0535      IF (CMD_PKT(2) .EQ. POSITION
0536      1 .OR.
0537      2 CMD_PKT(2) .EQ. READ
0538      3 .OR.
0539      4 CMD_PKT(2) .EQ. WRITE) THEN
0540
0541      FIELD = LIB$EXTZV(0,16,CMD_PKT(10))
0542      ENDIF
0543
0544      95  WRITE(LUN,95) CMD_PKT(11),FIELD
0545      FORMAT(' ',T30,Z2.2,/,T40,
0546      1 'REQUESTED BLOCK = ',I<COMPRESS4 (FIELD)>,'.')
0547
0548      CALL LINCHK (LUN,2)
0549
0550      100 WRITE(LUN,100) CHECKSUM_LO,CMD_PKT(12),CMD_PKT(13)
0551      FORMAT(' ',T8,A15,T30,Z2.2,/,T30,Z2.2)
0552      ENDIF
0553
0554      CALL LINCHK (LUN,3)
0555
0556      IF (END_PKT(0) .NE. 2) THEN
0557
```

```
0558  
0559  
0560 105 WRITE(LUN,105)  
0561 FORMAT(/' ', 'END PACKET HAS INVALID FLAG',/)  
0562  
0563 DO 115,I = 0,13  
0564 CALL LINCHK (LUN,1)  
0565  
0566 110 WRITE(LUN,110) END_PKT(1)  
0567 FORMAT(' ',T30,Z2.2)  
0568  
0569 115 CONTINUE  
0570 ELSE  
0571  
0572 WRITE(LUN,120)  
0573 120 FORMAT(/' ', 'END MESSAGE PACKET',/)  
0574  
0575 CALL LINCHK (LUN,2)  
0576  
0577 125 WRITE(LUN,125) END_PKT(0),CONTROL_PACKET  
0578 FORMAT(' ',T8,'FLAG',T30,Z2.2,/,T40,A19)  
0579  
0580 CALL LINCHK (LUN,2)  
0581  
0582 FIELD = LIB$EXTZV(0,8,END_PKT(1))  
0583  
0584 WRITE(LUN,130) PBYTE_COUNT,END_PKT(1),PBYTE_COUNT,  
0585 1 BYTE_COUNT(MAX(9,MIN(11,FIELD)))  
0586 130 FORMAT(' ',T8,A17,T30,Z2.2,/  
0587 1 T40,A17,A<COMPRESSC (BYTE_COUNT(MAX(9,MIN(11,FIELD))))>>  
0588  
0589 CALL LINCHK (LUN,2)  
0590  
0591 FIELD = LIB$EXTZV(0,8,END_PKT(2))  
0592  
0593 135 WRITE(LUN,135) OP_CODE,END_PKT(2),V2OP_CODE(MAX(63,MIN(65,FIELD)))  
0594 FORMAT(' ',T8,A7,T30,Z2.2,/  
0595 1 T40,A<COMPRESSC (V2OP_CODE(MAX(63,MIN(65,FIELD))))>>  
0596  
0597 CALL LINCHK (LUN,2)  
0598  
0599 140 WRITE(LUN,140) END_PKT(3)  
0600 FORMAT(' ',T8,'SUCCESS CODE',T30,Z2.2)  
0601  
0602 J = 12  
0603  
0604 DO 155,I = 0,11  
0605  
0606 IF (END_PKT(3) .EQ. V1SUCCESS_CODE(I)) J = I  
0607  
0608 155 CONTINUE  
0609  
0610 160 WRITE(LUN,160) V2SUCCESS_CODE(J)  
0611 FORMAT(' ',T40,A<COMPRESSC (V2SUCCESS_CODE(J))>>  
0612  
0613 CALL LINCHK (LUN,2)  
0614
```

```
0615      FIELD = LIB$EXTZV(0,8,END_PKT(4))
0616
0617      WRITE(LUN,170) END_PKT(4),UNIT,NUMBER,FIELD
0618 170    FORMAT(' ',T8,'UNIT',T30,Z2.2,7,T40,A14,
0619            1'I<COMPRESS4 (FIELD)>','.')
0620
0621      CALL LINCHK (LUN,1)
0622
0623      WRITE(LUN,175) UNUSED_BYTE,END_PKT(5)
0624 175    FORMAT(' ',T8,A11,T30,Z2.2)
0625
0626      CALL LINCHK (LUN,2)
0627
0628      WRITE(LUN,180) SEQUENCE_LO,END_PKT(6),END_PKT(7)
0629 180    FORMAT(' ',T8,A15,T30,Z2.2,/,T30,Z2.2)
0630
0631      CALL LINCHK (LUN,2)
0632
0633      FIELD = LIB$EXTZV(0,16,END_PKT(8))
0634
0635      WRITE(LUN,185) BYTECOUNT_LO,END_PKT(8),END_PKT(9),FIELD
0636 185    FORMAT(' ',T8,A17,T30,Z2.2,/,
0637            1'T30,Z2.2,T40,'BYTES TRANSFERED = ',I<COMPRESS4 (FIELD)>','.')
0638
0639      CALL LINCHK (LUN,2)
0640
0641      WRITE(LUN,190) END_PKT(10),END_PKT(11)
0642 190    FORMAT(' ',T8,'STATUS',T30,Z2.2,/,T30,Z2.2)
0643
0644      CALL OUTPUT (LUN,END_PKT(12),V1SUM_STATUS,4,4,7,'0')
0645
0646      CALL LINCHK (LUN,2)
0647
0648      WRITE(LUN,195) CHECKSUM_LO,END_PKT(12),END_PKT(13)
0649 195    FORMAT(' ',T8,A15,T30,Z2.2,/,T30,Z2.2)
0650      ENDIF
0651      endif
0652
0653      call linchk (lun,1)
0654
0655      write(lun,200)
0656 200    format(' ',:)
0657
0658      if (emb$w_hd_entry .ne. 98) then
0659
0660      call ucb$b_ertcnt (lun,emb$b_dv_ertcnt)
0661
0662      call ucb$b_ertmax (lun,emb$b_dv_ertmax)
0663      endif
0664
0665      call orb$l_owner (lun,emb$l_dv_ownuic)
0666
0667      call ucb$l_char (lun,emb$l_dv_char)
0668
0669      call ucb$w_sts (lun,emb$w_dv_sts)
0670
0671      call ucb$l_opcnt (lun,emb$l_dv_opcnt)
```



```
0672
0673      call ucb$w_errcnt (lun,emb$w_dv_errcnt)
0674
0675      if (emb$w_hd_entry .ne. 98) then
0676
0677      call ucb$l_media (lun,emb$l_dv_media)
0678
0679      call linchk (lun,1)
0680
0681      write(lun,200)
0682
0683      call tutape_qio (lun,emb$w_dv_func)
0684
0685      call irp$w_bcmt (lun,emb$w_dv_bcmt)
0686
0687      call irp$w_boff (lun,emb$w_dv_boff)
0688
0689      call irp$l_pid (lun,emb$l_dv_rqpid)
0690
0691      call irp$q_iosb (lun,emb$l_dv_iosb1)
0692      endif
0693
0694      RETURN
0695      END
```

PROGRAM SECTIONS

Name	Bytes	Attributes
0 \$CODE	3247	PIC CON REL LCL SHR EXE RD NOWRT LONG
1 \$PDATA	906	PIC CON REL LCL SHR NOEXE RD NOWRT LONG
2 \$LOCAL	2008	PIC CON REL LCL NOSHR NOEXE RD WRT LONG
3 EMB	512	PIC OVR REL GBL SHR NOEXE RD WRT LONG
Total Space Allocated	6673	

ENTRY POINTS

Address	Type	Name
0-00000000		TUTAPE

VARIABLES

Address	Type	Name	Address	Type	Name
2-000003EA	CHAR	BLOCK_LO	2-000003D9	CHAR	BYTECOUNT_LO
2-000003FD	CHAR	CHECKSUM_LO	2-000003A4	CHAR	COMMAND_PACKET
2-00000391	CHAR	CONTROL_PACKET	2-00000377	L*1	DIAGNOSTIC_MODE
3-0000001C	L*1	EMBSB_DV_CLASS	3-00000010	L*1	EMBSB_DV_ERTCNT
3-00000011	L*1	EMBSB_DV_ERTMAX	3-0000003E	L*1	EMBSB_DV_NAMING
3-0000003A	L*1	EMBSB_DV_SLAVE	3-0000001D	L*1	EMBSB_DV_TYPE

```

3-00000036 I*4 EMB$$_DV_CHAR
3-00000016 I*4 EMB$$_DV_IOSB2
3-0000004E I*4 EMB$$_DV_NUMREG
3-00000032 I*4 EMB$$_DV_OWNUIC
3-00000000 I*4 EMB$$_HD_SID
3-00000024 I*2 EMB$$_DV_BCNT
3-0000002C I*2 EMB$$_DV_ERRCNT
3-0000001A I*2 EMB$$_DV_STS
3-00000004 I*2 EMB$$_HD_ENTRY
2-0000040C I*4 FIELD
2-00000414 I*4 J
2-00000382 CHAR OP_CODE
3-0000005E I*4 RBUF
2-000003CA CHAR SEQUENCE_LO
2-00000386 CHAR UNUSED_BYTE
3-00000052 I*4 XCSR

```

```

3-00000012 I*4 EMB$$_DV_IOSB1
3-00000026 I*4 EMB$$_DV_MEDIA
3-0000002E I*4 EMB$$_DV_OPCNT
3-0000001E I*4 EMB$$_DV_RQPID
3-0000003F CHAR EMB$$_DV_NAME
3-00000022 I*2 EMB$$_DV_BOFF
3-0000003C I*2 EMB$$_DV_FUNC
3-0000002A I*2 EMB$$_DV_UNIT
3-0000000E I*2 EMB$$_HD_ERRSEQ
2-00000410 I*4 I
AP-00000004 L*1 LUN
2-00000389 CHAR PBYTE_COUNT
3-0000005A I*4 RCSR
2-00000378 CHAR UNIT_NUMBER
3-00000056 I*4 XBUF

```

ARRAYS

Address	Type	Name	Bytes	Dimensions
2-0000035C	CHAR	BYTE_COUNT	27	(9:11)
3-00000062	L*1	CMD_PKT	14	(0:13)
3-00000000	L*1	EMB	512	(0:511)
3-00000052	I*4	EMB\$\$_DV_REGSAR	420	(0:104)
3-00000006	I*4	EMB\$\$_HD_TIME	8	(2)
3-00000070	L*1	END_PRT	14	(0:13)
2-000001E0	CHAR	MODIFIER	10	(0:0)
2-00000098	CHAR	V1OP_CODE	280	(-1:12)
2-00000032	CHAR	V1RBUF	60	(12:15)
2-00000000	CHAR	V1RCSR	34	(6:7)
2-00000232	L*1	V1SUCCESS_CODE	12	(0:11)
2-000001EA	CHAR	V1SUM_STATUS	72	(4:7)
2-0000006E	CHAR	V1XCSR	6	(0:0)
2-000001B0	CHAR	V2OP_CODE	48	(63:65)
2-00000022	CHAR	V2RCSR	16	(11:11)
2-0000023E	CHAR	V2SUCCESS_CODE	286	(0:12)
2-00000074	CHAR	V2XCSR	36	(6:7)

LABELS

Address	Label	Address	Label	Address	Label	Address	Label	Address	Label
1-00000040	10'	1-00000052	15'	1-00000063	18'	**	19	1-0000007E	20'
1-000000A6	30'	1-00000087	40'	1-000000DE	42'	**	44	1-000000E7	45'
1-0000011B	55'	1-00000133	60'	1-00000156	65'	1-00000173	68'	1-00000192	70'
1-000001B2	80'	1-000001BF	85'	1-000001EC	90'	1-000001F9	95'	1-00000222	100'
1-00000258	110'	**	115	1-00000261	120'	1-0000027B	125'	1-00000291	130'
1-000002BF	140'	**	155	1-000002D8	160'	1-000002E4	170'	1-00000303	175'
1-00000323	185'	1-00000356	190'	1-0000036F	195'	1-00000382	200'		

FUNCTIONS AND SUBROUTINES REFERENCED

Type	Name	Type	Name	Type	Name	Type	Name	Type	Name
1*4	COMPRESS4	1*4	COMPRESSC		DHEAD1		FRCTOF		IRPSL_PID
	IRPSW_BCNT		IRPSW_BOFF	1*4	LIBSEXTZV		LINCHK		IRPSQ_IOSB
	TUTAPE_QIO		UCBSB_ERTCNT		UCBSB_ERTMAX		UCBSL_CHAR		OUTPUT
	UCBSW_ERRCNT		UCBSW_STS						UCBSL_OPCNT

0001
0002
0003
0004
0005
0006
0270
0271
0272
0273
0274
0275
0276
0277
0278
0279
0280
0281
0282
0283
0284
0285
0286
0287
0288
0289
0290
0291
0292
0293
0294
0295
0296
0297
0298
0299
0300
0301
0302
0303
0304
0305
0306
0307
0308
0309
0310
0311
0312
0313
0314
0315
0316
0317
0318
0319
0320

Subroutine TUTAPE_QIO (lun,emb\$w_dv_func)

include 'src\$:qiocommon.for /nolist'

byte lun

integer*2 emb\$w_dv_func

integer*4 qiocode(0:1,0:63)

if (qiocode(0,0) .eq. 0) then

qiocode(1,09) = %loc(io\$_search)

qiocode(1,11) = %loc(io\$_writepblk)

qiocode(1,12) = %loc(io\$_readpblk)

qiocode(1,26) = %loc(io\$_setchar)

qiocode(1,27) = %loc(io\$_sensechar)

qiocode(1,29) = %loc(io\$_diagnose)

qiocode(1,32) = %loc(io\$_writelblk)

qiocode(1,33) = %loc(io\$_readlblk)

qiocode(1,35) = %loc(io\$_setmode)

qiocode(1,39) = %loc(io\$_sensemode)

qiocode(1,48) = %loc(io\$_writevblk)

qiocode(1,49) = %loc(io\$_readvblk)

qiocode(1,50) = %loc(io\$_acress)

qiocode(1,51) = %loc(io\$_create)

qiocode(1,52) = %loc(io\$_deaccess)

qiocode(1,53) = %loc(io\$_delete)

qiocode(1,54) = %loc(io\$_modify)

qiocode(1,56) = %loc(io\$_acpcontrol)

qiocode(1,57) = %loc(io\$_mount)

do 10,i = 0,63

```
0321      qiocode(0,i) = 33
0322
0323      if (qiocode(1,i) .eq. 0) then
0324
0325      qiocode(1,i) = %loc(qio_string)
0326      endif
0327
0328      10      continue
0329      endif
0330
0331      call irp$w_func (lun,emb$w_dv_func,
0332      1 qiocode(0,lib$extzv(0,6,emb$w_dv_func)))
0333
0334      return
0335
0336      end
0337
```

PROGRAM SECTIONS

Name	Bytes	Attributes
0 \$CODE	225	PIC CON REL LCL SHR EXE RD NOWRT LONG
1 \$PDATA	8	PIC CON REL LCL SHR NOEXE RD NOWRT LONG
2 \$LOCAL	548	PIC CON REL LCL NOSHR NOEXE RD WRT LONG
3 QIOCOMMON	1247	PIC OVR REL GBL SHR NOEXE RD WRT LONG
Total Space Allocated	2028	

ENTRY POINTS

Address	Type	Name
0-00000000		TUTAPE_Q10

VARIABLES

Address	Type	Name	Address	Type	Name
AP-00000008a	I*2	EMBSW DV FUNC	2-00000200	I*4	I
3-00000442	CHAR	IOS_ABORT	3-00000340	CHAR	IOS_ACCESS
3-000003C2	CHAR	IOS_ACPCONTROL	3-000004B3	CHAR	IOS_AVAILABLE
3-00000297	CHAR	IOS_CLEAN	3-00000369	CHAR	IOS_CREATE
3-00000385	CHAR	IOS_DEACCESS	3-00000393	CHAR	IOS_DELETE
3-0000026D	CHAR	IOS_DIAGNOSE	3-00000065	CHAR	IOS_DRVCLR
3-000004CB	CHAR	IOS_DSE	3-000000A9	CHAR	IOS_ERASETAPE
3-00000276	CHAR	IOS_FORMAT	3-00000071	CHAR	IOS_INITIALIZE
3-00000014	CHAR	IOS_LOADMCODE	3-000003A1	CHAR	IOS_MODIFY
3-000003E2	CHAR	IOS_MOUNT	3-00000000	CHAR	IOS_NOP
3-0000009D	CHAR	IOS_OFFSET	3-000000EB	CHAR	IOS_PACKACK
3-000000E0	CHAR	IOS_QSTOP	3-000003EF	CHAR	IOS_RDSTATS
3-00000421	CHAR	IOS_READCSR	3-00000169	CHAR	IOS_READHEAD

3-000002B6	CHAR	IOS_READLBLK	3-0000013F	CHAR	IOS_READPBLK
3-00000200	CHAR	IOS_READPRESET	3-00000195	CHAR	IOS_READTRACKD
3-0000033A	CHAR	IOS_READVBLK	3-0000045A	CHAR	IOS_READWTHBUF
3-00000484	CHAR	IOS_READWTHXBUF	3-0000004D	CHAR	IOS_RECAL
3-0000007C	CHAR	IOS_RELEASE	3-000001AB	CHAR	IOS_REREADN
3-000001B8	CHAR	IOS_REREADP	3-000000CA	CHAR	IOS_RETCENTER
3-000002E6	CHAR	IOS_REWIND	3-000002C9	CHAR	IOS_REWINDOFF
3-000000FC	CHAR	IOS_SEARCH	3-00000024	CHAR	IOS_SEEK
3-00000231	CHAR	IOS_SENSECHAR	3-00000309	CHAR	IOS_SENSEMODE
3-0000021D	CHAR	IOS_SETCHAR	3-000003B8	CHAR	IOS_SETCLOCK
3-00000088	CHAR	IOS_SETCLOCKP	3-000002DD	CHAR	IOS_SETMODE
3-000002ED	CHAR	IOS_SKIPFILE	3-000002FA	CHAR	IOS_SKIPRECORD
3-00000029	CHAR	IOS_SPACEFILE	3-0000010E	CHAR	IOS_SPACERECORD
3-000003D7	CHAR	IOS_STARTDATA	3-000000B4	CHAR	IOS_STARTDATAP
3-00000037	CHAR	IOS_STARTMPROC	3-0000020F	CHAR	IOS_STARTSPNDL
3-00000059	CHAR	IOS_STOP	3-0000000D	CHAR	IOS_UNLOAD
3-0000046B	CHAR	IOS_WRITEBUFNCRC	3-0000011E	CHAR	IOS_WRITECHECK
3-000001E4	CHAR	IOS_WRITECHECKH	3-000003FF	CHAR	IOS_WRITECSR
3-00000153	CHAR	IOS_WRITEHEAD	3-000002A2	CHAR	IOS_WritelBLK
3-00000247	CHAR	IOS_WRITEMARK	3-00000314	CHAR	IOS_WRITEOF
3-0000012A	CHAR	IOS_WRITEPBLK	3-000001C9	CHAR	IOS_WRITERET
3-0000017E	CHAR	IOS_WRITETRACKD	3-00000326	CHAR	IOS_WRITEVBLK
3-00000448	CHAR	IOS_WRITEWTHBUF	3-00000257	CHAR	IOS_WRTTMKR
AP-00000004a	L*1	LUN	3-000004A1	CHAR	QIO_STRING

ARRAYS

Address	Type	Name	Bytes	Dimensions
2-00000000	I*4	Q10CODE	512	(0:1, 0:63)

LABELS

Address	Label
**	10

FUNCTIONS AND SUBROUTINES REFERENCED

Type	Name	Type	Name
	IRP\$W_FUNC	I*4	LIB\$EXTZV

COMMAND QUALIFIERS

FORTRAN /LIS=LIS\$:TUTAPE/OBJ=OBJ\$:TUTAPE MSRC\$:TUTAPE

/CHECK=(NOBOUNDS,OVERFLOW,NOUNDERFLOW)

/DEBUG=(NOSYMBOLS,TRACEBACK)

/STANDARD=(NOSYNTAX,NOSOURCE FORM)

/SHOW=(NOPREPROCESSOR,NOINCLUDE,MAP)

/F77 /NOG_FLOATING /I4 /OPTIMIZE /WARNINGS /NOD_LINES /NOCROSS_REFERENCE /NOMACHINE_CODE /CONTINUATIONS=19

E 12
16-Sep-1984 00:16:59
5-Sep-1984 14:24:09

VAX-11 FORTRAN V3.4-56 Page 16
DISK\$VMSMASTER:[ERF.SRC]TUTAPE.FOR;1

```
Run Time: 11.14 seconds
Elapsed Time: 29.09 seconds
Page Faults: 266
Dynamic Memory: 251 pages
```

[illegible]

0154 AH-BT13A-SE DIGITAL EQUIPMENT CORPORATION
VAX/VMS V4.0 CONFIDENTIAL AND PROPRIETARY

DIGITAL EQUIPMENT CORPORATION
CONFIDENTIAL AND PROPRIETARY